



**At the first use, plug the battery on the machine and charge it before to use.**



Slide The brush under the deck.



Raise down the brush deck by pushing on the rear of the pedal.




Turn "ON" the key. Turn the speed knob completely on left.



Switch « ON » the brush motor.



Push one time on pedal, brush is installed.



Install and screw the squeegee, plug the hose.



On the back of the machine, full fill in water up to 72 liters and add detergent.



Adjust flow of water by pushing +/-



Push on the switch **up** or **down** to get **forward** or **reverse** traction.



Raised down the level handle of squeegee, vacuuming is turning "ON" automatically and turns "OFF" when you lift it up.



Adjust the maximum speed with the knob.



Turn on the flashing light during the cleaning of the floor and during the transport of the machine.




Turn the screw on the arm of the squeegee to adjust picking water on the rear squeegee.



The squeegee must be adjusted until it's dry behind the squeegee of the machine.



At the end of the work, raise up the brush deck and lift up squeegee. Turn "OFF" brush motor and flow of water.



To uninstall the brush, the deck must be in high position and just push on the button.



Turn "OFF" the key and the flashing light.



Emptying the tank of dirty water and rinse it. Remove the floating system and rinse the ball inside. Keep it clean.



Unplug the hose from the squeegee to uninstall the complete body of squeegee.



Rinse and clean the squeegee with fresh water. Check the squeegee blades and return them if needed.



Open the cap of the solution tank to emptying the machine. If you change of chemical rinse the tank before to refill in water.



For storing the squeegee you can attached it on the back of the machine.



Keep the cover open when the machine is stored.




USB plug to charge mobile during working time of the machine.



Charger power cable store under the seat.



Plug the cable on the charger and to the power. **Light turn green when it's fully charged.**



Read carefully the user manual.



Local Viper dealer:

.....

Phone number:

.....

SN:.....